



# Electronic Test Max Min Thermometer



## Operating Instructions

1. To switch on the thermometer press the **ON /OFF** button.
2. To select °C or °F display press the **°C / °F** button on the back of the thermometer.
3. To measure a temperature insert the stainless steel probe into the medium being measured and the temperature will be displayed on the screen.
4. The thermometer stores the maximum and minimum temperatures in its memory. To view: Press the **Min-Max** button once to display the highest temperature [**MAX** is displayed]. Press the **Min-Max** button twice to display the lowest temperature [**MIN** is displayed].
5. To reset the memory press the **Min-Max** button once to display the highest temperature [**MAX** is displayed] then press the **Clear** button to reset the maximum memory. [--- is displayed]. Press the **Min-Max** button twice to display the lowest temperature [**MIN** is displayed] and then press the **Clear** button to reset the minimum memory. [--- is displayed].
6. The thermometer is fitted with a LR44 button cell. Estimated battery life is 2 years.

- Caution**
- Always keep the thermometer head away from direct heat or cold source
  - The probe is very sensitive: do not use an abrasive to clean it.

**Brannan Thermometers**  
Cleator Moor Cumbria  
England  
[www.brannan.co.uk](http://www.brannan.co.uk)