

290512



Waterproof Thermometer

with Stainless Steel Probe

Operating Instructions

- Press ON/OFF - thermometer will execute self test then be ready for use.
- To obtain accurate reading, insert probe minimum of 30mm into substance being tested.
- To change from °C to °F press and hold °C / °F Button for 4 seconds then release.
- Press ON/OFF again for 6 seconds to switch off. Thermometer will automatically switch off after ten minutes of non use.

- Range: -40°C to +240°C & °F
- Accuracy: +/-1°C between 0 and 100°C otherwise +/-2°C

Hold feature

- Press hold to maintain the temperature displayed.

Max Min memory feature

- Press the Max / Min button to display maximum temperature since instrument was switched on.
- Press again to display the minimum temperature.
- Press a third time to display the current temperature.
- To reset memory, switch instrument off and on again.

Caution

- Always keep the thermometer head away from direct heat or cold.
- The probe is very sensitive: do not use an abrasive to clean.
- Do not use in a microwave or conventional oven.

Changing the Battery

- Loosen all the screws on the back of the case, replace the battery and refit the screws.



Brannan Thermometers

Cleator Moor Cumbria
England

www.brannan.co.uk