

# Electronic Test Thermometer

## Instructions

1. To switch on the thermometer:  
press the **POWER ON/OFF** button on the back of the thermometer.
2. To select °C or °F display:  
press the **°C/°F** button on the back of the thermometer.
3. To measure a temperature:  
Insert the stainless steel probe into the medium being measured and the temperature will be displayed on the screen.
4. To set the alarm temperature:  
Press and hold the **UP** or **DOWN** buttons for two seconds to enter setting mode. The alarm temperature will now be flashing on the screen.  
Adjust the alarm temperature using the **UP** and **DOWN** buttons.  
Release all buttons for 4 seconds to lock the setting.
5. To switch on the alarm:  
Press the **STOP ON/OFF** button once to switch on the alarm. The alarm symbol will show on the screen.  
When the alarm temperature is reached the alarm will sound and the light will flash.  
To switch off the alarm sound press the **STOP ON/OFF** button.
6. The thermometer is fitted with a LR44 button cell. Estimated battery life is 2 years.

### Caution

- Always keep the thermometer head away from direct heat or cold.
- The probe is very sensitive: do not use an abrasive to clean it.