User's Manual

Professional Light Meter



Please read this user's manual thoroughly before using this unit and keep it properly for your future reference.

Contents

| 1. Safety 2 |
|-----------------------------|
| 2. Application 3 |
| 3. Features 3 |
| 4. Specifications 4 |
| 5. Meter Description 6 |
| 6. LCD Display Description8 |
| 7. Operation Instruction9 |
| 8. Notes |
| 9. Accessories |

1. ASafety

Read the following safety information carefully before attempting to operate or service the meter.

Use the meter only as specified in this manual; otherwise, the protection provided by the meter may be impaired.

▲ Environment conditions:

- RH≤90% (Non-Condensation)
- Operating Temperature: -20 $^\circ C \sim 60 ^\circ C$
- Storage Temperature: -20 $^\circ$ C \sim 60 $^\circ$ C

Maintenance

- Repairs or servicing not covered in this manual should only be performed by qualified personnel.
- Wipe the unit with a dry soft cloth. Do not use abrasives or solvents on this instrument.

▲ Safety Symbol

(Comply with EMC

2. Application

This Light Meter is designed to meet the measurement requirements of safety Engineers, Health, Industrial safety offices and light quality control in various environments like factory, school, construction, etc.

3. Features

- Measuring range: 0Lux ~ 400kLux / 0Fc~ 40kFc (Measurement repeatability)
- Analog bar-graph indication
- Real time and date display
- High accuracy
- Data hold
- Meter corrected for spectral relative efficiency
- Automatically revise parameters for onstandard illumination
- Short rise and fall times
- Selectable measuring units: Lux or Fc
- Meter automatically shuts down after approx. 15 minutes of inactivity
- MAX/MIN record
- Large LCD display

- Peak-hold
- 4-level selectable measurement ranges
- Automatic measurement
- Low battery indication

4. Specifications

- Display: 4 digits LCD display
- Measuring range: 0 Lux~400k Lux, 0Fc~ 40k Fc
- Spectral response: CIE photopic (CIE human eye response curve)
- Over range indication:LCD displays "-OL-" or "-LO-"
- Spectral accuracy: CIE Vλ function


```
(f1' \le 6\%, f2' \le 2\%)
```


Accuracy: ±3% rdg±0.5%f.s.(<10,000Lux)</p>

±4% rdg±10dgts.(>10,000Lux)

- Sampling rate: 2 times per second
- Photo detector: Silicon photo-diode with spectral response filter
- Power supply: One 9V battery, 006P, NEDA1604 or IEC6F22
- Photo detector Lead Length: approx. 2.5m
- Dimension(L*W*H): 185*66*33(mm)
- Weight: 308g


5. Meter Description





- 1. Photo detector
- 2. Photo detector socket
- 3. LCD display
- 4. SET key
- 5. Backlight ON/OFF key
- 6. Lux/Fc selection key
- 7. Range level selection key
- 8. Power ON/OFF key
- 9. MAX/MIN key
- 10. HOLD key
- 11. PEAK key
- 12. Tripod nut
- 13. Battery compartment

6. LCD Display Description



- 1. Low range indication icon
- 3. Peak icon
- 5. Range indication
- 7. Date & Time display
- 9. Date & Time icon
- 11.Low battery icon
- 13.Hold icon

- 2. MAX/MIN icon
- 4. Over range indication icon
- 6. Analog bar-graph indication
- 8. LUX/FC record
- 10.Auto power off icon
- 12.Lux/Fc icon
- 14.Auto range icon

7. Operation Instruction

- (1) Power ON/OFF Function: press" (*) " key for one second, the meter will be on; keep pressing this key for approx. 3 seconds, the meter will be off.
- (2) Date & Time Set: keep pressing the "^(T)" key before power the meter on, then power the meter on and release this key when the DATE icon and data flash,enter into the Date & Time Set mode, the display will be YEAR-MONTH-DAY, fig.as below:


DATE 0 0.0 0.0 0


When the YEAR data flashes continuously, press



Press "I" the second time,the MONTH data will flash continuously,then press "I and "I to increase or decrease the value.See fig.as below:









After finish the Date & Time set, press "PEAK" key to save the data and exit this mode.



After turning the meter on, momentarily press " key, the backlit will be on/off, it will automatically turn off after approx. 30 seconds of inactivity.

(4) Fc/Lux Selection

Press the "" key to select Fc units or Lux units.

(5) Range selection

Press" $\overset{(\nabla)}{}$ key to select the range level, there are four

selectable levels:

 $\begin{array}{l} 0 \ \sim \ 400 \ \text{Lux}; 400 \ \sim \ 4k \ \text{Lux} \\ 4k \ \sim \ 40k \ \text{Lux}; 40k \ \sim \ 400k \ \text{Lux} \\ \text{AUTO range:} \ 0 \ \sim \ 400k \ \text{Lux} \end{array}$

(6) MAX/MIN

In the measurement mode, press "We we one time, "MAX" icon will appear on the LCD to view the current MAX reading, press the button again, "MIN" icon will appear to view the current MIN reading. Press this key once more to exit the MAX/MIN mode.

(7) Data Hold

Press " key one time, "HOLD" icon will appear on the LCD, which indicates the data is freezed. To release the held reading, press the key again.

(8) PEAK

Press "Press" button one time, "PEAK" icon will appear on the upper right of LCD, the PEAK value will be displayed. Press this key again to exit the PEAK mode.

8. Notes

- (1) When the low battery icon " appears, replace the meter's battery.
- (2) Check whether the photo detector is well connected with the photo detector socket before measurement.
- (3) When manual range is needed, press "LEVEL" key to select the desired range, if "UNDER" or "OVER" icon appears on the LCD, which indicates incorrect range and need to select again.
- (4) Remove the battery when the meter is to be stored for long periods of time to avoid battery leakage.
- (5) If the date and time automatically resume to default setting after power the meter on, which indicates the battery power is low, replace the meter's battery.

9. Accessories

- User's manual
- ② Photo detector
- 3 9V battery
- ④ Tripod(Optional)