

## pH51 Waterproof pH Tester

### pH51 Waterproof pH Tester with replaceable electrode

These instruments are designed for all applications. Its' IP65 Waterproof casing and double junction (for pH) replaceable electrode make them suitable also for heavy duty applications, such as Waste Water treatment and Agriculture. The modular design allows easy electrode and battery replacement.

All Waterproof testers are supplied in a leather casing complete with calibration solution, batteries, instruction manual and screwdriver for calibration.

The pH51 is a waterproof pH tester with 2 points manual calibration,  $\pm 0.1$  pH accuracy and a range of 0.0 to 14.0 pH.



#### Replaceable pH electrode

Replace the electrode in a fast and simple way yourself! Just unscrew the plastic ring on the top of the electrode and replace the electrode with a new one.



**Calibration, Maintenance & Cleaning Solutions**  
 Choose from our wide selection of calibration, maintenance and cleaning solutions.

#### SPECIFICATIONS

Range	0.0 to 14.0 pH
Resolution	0.1 pH
Accuracy	$\pm 0.1$ pH
Typical EMC Deviation	$\pm 0.1$ pH
Calibration	manual, at 2 points through trimmers
pH Electrode	MA73600 (replaceable)
Environment	0 to 50°C; max RH 100%
Battery Type	3 x 1.5V (included)
Battery Life	More than 1500 hours of continuous use
Dimensions	165 x 30 x 30 mm
Weight	80 g

#### ACCESSORIES

MA73600	Replaceable pH electrode
M10004B	pH 4.01 buffer solution 20 ml sachet (25 pcs)
M10007B	pH 7.01 buffer solution 20 ml sachet (25 pcs)
M10010B	pH 10.01 buffer solution 20 ml sachet (25 pcs)
MA9016	Electrode cleaning solution, 230 ml
M10000B	Electrode rinse solution, 20 ml (25 pcs)

#### ORDERING INFORMATION

pH51 is supplied in a carton box complete with calibration solution, batteries, instruction manual and screwdriver for calibration.