

pH55/56

Pocketsize pH/Temperature Meters with replaceable electrode

Water-resistant pH testers with Large dual-level LCD that displays pH and temperature (°C or °F). The large display shows readings in an extended range from -2.0 to 16.0 pH (pH56 has a 0.01 pH resolution) and simultaneously shows temperature from -5.0 to 60.0°C or 23.0 to 140.0°F. They have a stability indicator and hold function that freezes the display for easy and accurate recording. The large display also has graphic symbols to guide you through all operations.

Complete with a temperature probe for fast and more precise temperature measurement they compensate automatically for temperature. Calibration is made automatically in 1 or 2 points with memorized standard and NIST buffer sets. Auto power OFF saves battery power after non-use.

The double-junction electrode can be replaced in a very fast and simple way! The modular design allows easy electrode and battery replacement.



- Years warranty **2**
- ATC
- IP65
- Points **2**
- AUTO Buffer
- Dual Display
- Self Diagnostic
- CE
- Electrode Replaceable

Specifications	pH55	pH56
Range	pH -2.0 to 16.0 pH Temp. -5.0 to 60.0°C / 23.0 to 140.0°F	-2.00 to 16.00 pH -5.0 to 60.0°C / 23.0 to 140.0°F
Resolution	pH 0.1 pH Temp. 0.1°C / 0.1°F	0.01 pH 0.1°C / 0.1°F
Accuracy (@25°C)	pH ±0.1 pH Temp. ±0.5°C / ±1°F	±0.05 pH ±0.5°C / ±1°F
Typical EMC Deviation	pH ±0.1 pH Temp. ±0.3°C / ±0.6°F	±0.02 pH ±0.3°C / ±0.6°F
Calibration	automatic, 1 or 2 points with 2 sets of memorized buffers (pH 4.01, 7.01, 10.01 or 4.01, 6.86, 9.18)	automatic, 1 or 2 points with 2 sets of memorized buffers (pH 4.01, 7.01, 10.01 or 4.01, 6.86, 9.18)
Temperature Compensation Probe	automatic from -5 to 60°C M156P (replaceable)	automatic from -5 to 60°C M156P (replaceable)
Environment	-5 to 50°C / 32 to 122°F; max RH 100%	-5 to 50°C / 32 to 122°F; max RH 100%
Battery Type	4 x 1.5V; IEC LR44, A76 (included)	4 x 1.5V; IEC LR44, A76 (included)
Battery Life	approx. 300 hours of use after 8 minutes of non-use	approx. 300 hours of use after 8 minutes of non-use
Packaging dimensions	254 x 67 x 47 mm	254 x 67 x 47 mm
Packaging weight	200 g	200 g

pH/Temperature Sensor

The pH55 and pH56's exposed temperature sensor provides fast response time, and its proximity to the pH electrode guarantees much more accurate temperature compensated readings.



Accessories

- M156P** Replaceable electrode for pH55 & pH56
- M10000B** Electrode rinse solution, 20 mL sachet (25 pcs)
- M10004B** pH 4.01 buffer solution 20 mL sachet (25 pcs)
- M10007B** pH 7.01 buffer solution 20 mL sachet (25 pcs)
- M10010B** pH 10.01 buffer solution 20 mL sachet (25 pcs)
- MA9004** pH 4.01 buffer, 230 mL bottle
- MA9007** pH 7.01 buffer solution, 230 mL bottle
- MA9010** pH 10.01 buffer solution, 230 mL bottle
- MA9015** Electrode storage solution, 230 mL
- MA9016** Electrode cleaning solution, 230 mL
- MA753** Hard carrying case for 2 testers

Ordering Information

pH55 and pH56 is supplied complete with protective cap, 20 mL pH 4.01 and pH 7.01 sachets of calibration solution.

Packaging Information

pH55 and pH56 can be supplied in a carton box or in a tubular plastic casing. Optionally pH55 is also available in a kit (M15559 or M15560) together with EC59 or EC60 EC/TDS/Temp Meters.

Replaceable electrode

Replace the electrode in a fast and simple way yourself! Just unscrew the plastic ring on the top of the electrode and replace the electrode with a new one.

